BOWMAN<sup>®</sup> Dispensers Organize · Contain · Comply<sup>®</sup>

## **PS004–0212** Protection System – Glove and Bag



### Related Products (each sold separately):

PS004-0111: Protection System - Glove and Bag (shown below)



### **Product Description:**

- Protection System Glove and Bag
- Holds three boxes of gloves and one roll of individualsized biohazard, linen, or garbage bags
- Two-way keyholes for wall mounting
- Quartz Beige ABS Plastic

Primary Area for Product Usage:

Anywhere personal protection equipment is needed

Dispenses:

- Box(es) no larger than 5.25"W x 10.00"H x 3.75"D (13.3 cm x 25.4 cm x 9.5 cm)
- Rolls no larger than 10.00"W x Ø3.40" (25.4 cm x 8.6 cm) Product Specifications (overall external dimensions):
- 10.10"W x 20.40"H x 3.95"D (25.7 cm x 51.8 cm x 10.0 cm)
- 1.3 lbs (0.6 kg) approximated

**Mounting Specifications:** 



#### Package Specifications:

- Package Quantity: 3 per case
  - 21"W x 14"H x 10"D (53.3 cm x 35.6 cm x 25.4 cm)
  - -6.0 lbs (2.7 kg) approximated
- Package Quantity: 1 per case
  -24"W x 12"H x 6"D (61.0 cm x 30.5 cm x 15.2 cm)
  -2.0 lbs (0.9 kg) approximated

BOWMAN<sup>®</sup> Dispensers Organize- Contain - Comply<sup>®</sup>

# **PS004–0212** Protection System – Glove and Bag

Installation Instructions/Characteristics & Care

## Installation

Always mount dispensers securely prior to loading with product.



 Mount securely to a wall with screws approved and supplied by building maintenance.

2

### Parts included:

- Dispenser
- **Tools Required:**
- No tools required to assemble dispenser

Care and Construction ABS Plastic

## **Material Characteristics**

Designed for Long-Term, Heavy-Duty Applications

The combination of copolymers (Acrylonitrile, Butadiene, and Styrene) gives ABS an excellent combination of strength, rigidity, and toughness. The fauxwood finish is ARVINYL laminate created from a semi-rigid film.

ABS is chemical and stress-crack resistant. It is tough, dimensionally stable, and will hold up to long-term use. To ensure product longevity, fauxwood products should not be mounted in very hot or cold areas.

## **Care and Cleaning**

Use mild soap and water to clean. Petroleum-based oils, solvents, and paints should not be used.

Standard hospital cleaning supplies are approved for use on our ABS plastic products.